



| J1 PIN # | COLOR  | WIRE PN           | J2 PIN # |
|----------|--------|-------------------|----------|
| 1        | RED    | H3BXG-10104-R4-ND | 1        |
| 3        | BLUE   | H3BXG-10104-L4-ND | 2        |
| 5        | YELLOW | H3BXG-10104-Y4-ND | 3        |
| 7        | GREEN  | H3BXG-10104-G4-ND | 4        |
| 9        | WHITE  | H3BXG-10104-W4-ND | 5        |
| 11       | BROWN  | H3BXG-10104-N4-ND | 6        |
| 13       | GRAY   | H3BXG-10104-S4-ND | 7        |
| 15       | VIOLET | H3BXG-10104-V4-ND | 8        |
| 20       | BLACK  | H3BXG-10104-B4-ND | 9        |

## ASSY PROCEDURE

1. INSERT PRE-CRIMPED WIRES INTO J2 WITH THE LABELED COLOR SCHEME
2. PLACE SHRINK TUBING OVER ALL WIRES, DO NOT APPLY HEAT
3. SOLDER BARE END OF WIRE TO J1 AS SHOWN IN THE PINOUT
4. ADD POWER JUMPER WIRES TO PIN 1 AND PIN 20 OF J1 IF NEEDED
5. APPLY HEAT TO SHRINK TUBE OVER WIRE AND CONNECTIONS TO J1 TERMINALS

## NOTES

1. ALL CONNECTION WIRES WILL BE 4"
2. POWER JUMPER WIRES IF NEEDED ARE 2'

J1  
TYCO  
5103308-5  
A33165-ND



J2  
HIROSE  
DF11-10DS-2C  
H2023-ND



|                            |                             |              |
|----------------------------|-----------------------------|--------------|
| Title                      |                             |              |
| ARMDIMM JTAG CABLE ADAPTER |                             |              |
| Size                       | Document Number<br><Doc>    | Rev<br>1     |
| Date:                      | Wednesday, January 28, 2009 | Sheet 1 of 1 |