

## 4.3" Resistive Touch Screen LCD GUI Development Kit

Congratulations on the purchase of your  $\mu$ EZ<sup>®</sup> GUI development kit!  
Our goal is to ensure you have a pleasant experience familiarizing yourself with the functions and capabilities of our products.

### To Begin Development with your $\mu$ EZ GUI:

1. Power on the device by connecting the provided 5V power adapter to one end of the USB cable and the other end to the  $\mu$ EZ GUI USB connector, P1. **Note:** Do not connect the  $\mu$ EZ GUI to a computer USB port. Standard USB 2.0/3.0 ports will not provide sufficient power to the device.
2. Visit [TeamFDI.com/StartHere](http://TeamFDI.com/StartHere) to download the UEZGUI-4088-43WQH Start Here Guide. This guide will provide step-by-step instructions and supporting files for designing your first graphical user interface.



## UEZGUI-4088-43WQH Kit Contents

- 4.3" Resistive Touch Screen LCD GUI Production Module  
(Part number: UEZGUI-4088-43WQH-BA)
- SEGGER J-Link™ Lite ARM Probe
  - 20 Pin Ribbon Cable
- FDI 20 Pin to mini 10 Pin J-Link Adapter (Part Number: JLINK-ARM-AD)
- Two USB Type A to USB Type Mini-B USB Cables
- Universal AC to 5V USB Plug Power Supply Unit

### Also Included:

- Expansion board for  $\mu$ EZ GUI with 70-pin breakout and optional RS232.  
**Note:** The 4-bit microSD card slot is not designed for this  $\mu$ EZ GUI.  
(Part Number: UEZGUI-EXP-BRKOUT)
- 20 Pin Flex Cable
- 50 Pin Flex Cable